

Fieldpiece Stick Meters

The Perfect Fit for Any HVAC/R Job.

Slide on any Accessory Head and switch to the mV Scale to read measurement directly.

HVAC/R Features



HS33



HS35

Magnetic Hanger



Lead Storage in Back



Remote Testing



Single Handed Testing



HS36

Expand with Accessory Heads!



CO



Pressure



Air Velocity



Superheat



Dual Temp

Start with the Stick, do more with the Heads.

Flame Rectification, Hi-Volt Diode, Subcooling, IR Temp. Vacuum Gauge
Amps AC/DC, %CO₂, %O₂, Dew Pt, %RH, WB, Dual Temp, Volts.



